

ROSER Manual INSTALLATION Manual



TOOLS REQUIRED






Safety Shoes



Hammer and Screw Gun



Snips





Sealant




Crayon Marker



Nails and Srews




MORE TOOLS REQUIRED



CLEO ACCESSORIES




BATTEN INSTALLATION




INSTALL BIRD-STOP

Local Code Approved (Underlayment) **Bird Stop Eave Bird Stop Eave Cutting Location Bird Stop Eave**

CLEO TILE PLACEMENT



CLEO TILE PLACEMENT CONTINUED




Point of overlapping







LAY CLEO TILE FROM TOP TO BOTTOM WHEN INSTALLING ON BATTENS



RAKE GABLE INSTALLATION









BIRD STOP RIDGE INSTALLATION




CLEO TILE HIP & RIDGE INSTALLATION RAKE GABLE EDGE




CLEO TILE HIP & RIDGE INSTALLATION RIDGE COURSE



CLEO TILE HIP & RIDGE INSTALLATION HIPS




VALLEY TYPE 2 INSTALLATION






BATTENLESS

CLEO TILE RAKE GABLE DETAIL



BATTENLESS


INSTALLING ROOFING PANELS





BATTENLESS

VALLEY TYPE 1 INSTALLATION





CLEO

ROSER Manual



Stone Coated Steel Roof

www.ROSER.com















SEOUL MARKETING OFFICE

One Bldg.12F.,121, Teheran-ro, Gangnam-gu,
Seoul, KOREA. T +82 2 566 7663

Marketing@roser.com F +82 2 563 7663

HEAD OFFICE / FACTORY

43, Nae-Ri-19, Amnyang-myeon, Gyeongsan-si, Gyeongsangbuk-do, KOREA. T +82 53 817 5000 Roser@roser.com F +82 53 817 5454