STEELGUARD

> INSTALLATION MANUAL





STEEL GUARD TILE



Overal Length	1295mm (50.98")
Length of Cover	1225mm (48.22")
Width of Cover	395mm (15 . 55")
Roof Cover/Tile	0.483m² (5.19ft²)
Coverage	2.07 tile/m²
Weight/unit	2,9kg (6.39lb)

CLEAN AND BEAUTIFUL

Hidden fastening system eliminates all exposed fasteners for a clean look.




SIMPLE AND ECONOMICAL

The ${\bf Hidden\ Fastening\ system}$ designed for direct to solid sheathing installation.





ACCESSORIES






Installation Guidelines

No grinding and cutting on roof

– Do not cut panels or accessories on the roof as particles will rust on the surface.

2 No vertical aligning of tiles


- Stagger panels for optimal appearance, DO NOT rack panels directly above one another.








STARTER STRIP AT FASCIA







INSTALLING ROOFING PANELS













FIX THE MISSION TRIM TO THE EDGE OF THE ROOF










Two options are available forrake edge treatments, standard trim cap secured to timber batten running up the rake with panels folded up and Stone Coated Rake channel with standard drip edge along the rake.



RIDGE










HIP INSTALLATION








Two options are available for rake edge treatments, standard trim cap secured to timber batten running up the rake with panels folded up and Stone Coated Rake channel with standard drip edge along the rake.




HIP INSTALLATION





HIP INSTALLATION









ROSER

VALLEYS











VALLEYS













VALLEYS





WALL FLASHING






WALL FLASHING







STEELGUARD NSTALLATION MANUAL

ROSER ROOFING SYSTEM